
INSTALLATION OF BUTTONS ON PSFxx Wall stations



Snap Off the front cover

Turn Button 45 degrees to insert in or extract from PSFxx .